

Characteristics













Pharma Cleanroom Accessories Applications Applications Included

Activated Carbon

Corrosive Recovery

Protective Clothing



- *Cleanroom compatible. Can be used in the pharmaceutical industry when equipped with stainless steel 4-wheel dolly or tilting cart
- Designed for the recovery of acids and corrosive liquids
- To be used as a recovery unit in conjunction with a vacuum
- Available with a Middle Ring with KINA 3® Activated Carbon (MRAC) for the adsorption of Chloride and acid vapors (HF, HCL, etc). Other types or carbon available.
- For liquid recovery
- Acid-resistant high-density polyethylene, nylon and pvc
- Recovery capacity of 12.5 gallons (48 liters)
- Available with a 4-wheel dolly, tilting cart or hydro-cart. 4-wheel dolly and tilting cart available in stainless steel
- Includes a complete tool kit

Acid-resistant high-density polyethylene, nylon and pvc. These units were designed for the recovery of acid as well as other corrosive liquids. These units are available on a variety of powder coated or stainless steel carts. Also available with a Middle Ring with Activated Carbon Cartridge. Different types of carbon are available for the adsorption of toxic/nuisance fumes and vapors. These recovery units are to be used in conjunction with a vacuum cleaner system.

Specifications

	Unit	ARU-15 STD (4W)	ARU-15 STD (4W) MRAC	ARU-15 CR (4W)	ARU-15 CR (4W) MRAC	ARU-15 STD (TC)	ARU-15 STD (TC) MRAC	ARU-15 CR (TC)	ARU-15 CR (TC) MRAC	ARU-15 STD (HY-C) MRAC
Part#		211860	211864	211862	211865	211870	211866	211874	211878	211863
Filter Clean- ing		NONE	NONE	NONE	NONE	NONE	NONE	NONE	NONE	NONE
Wet Recovery Gal	Gal	12.5	12.5	12.5	12.5	12.5	12.5	12.5	12.5	12.5

Middle Ring with Activated Carbon

Activated carbon is used for the adsorption of toxic/nuisance fumes and vapors. Tiger-Vac offers a variety of activated carbons for various applications such as for the recovery of fuels, mercury, chloride and acid vapors and for Arsine and Phosphine.

FILTERS - In	cluded	1
Part#	Qty	Description
211749	1	LIQUID FILTER ASSEMBLY

ACTIVATED	CARBO	ON CARTRIDGE - Optional
Part#	Qty	Description
212200B	1	CARBON CARTRIDGE ASSEMBLY WITH 3mm CARBON (REGULAR)
212200C	1	CARBON CARTRIDGE ASSEMBLY WITH 3mm MERSORB (FOR MERCURY VAPORS)
212200K	1	CARBON CARTRIDGE ASSEMBLY WITH 3mm KOGC3/KINA3 CARBON (FOR CHLORIDE VAPORS)
212200L	1	CARBON CARTRIDGE ASSEMBLY WITH 3mm A-3 CARBON (FOR ARSINE AND PHOSPHINE VAPORS)

TOOLS AND	ACCE	SSORIES - Included
Part#	Qty	Description
381337	1	VINYLIFE HOSE ASSEMBLY 1.5"(38mm) \times 10'(3m) FOR USE w/ARU, w/PLASTIC FEMALE CAMLOCKS ON BOTH ENDS
381336	1	PVC CONNECTION HOSE ASSEMBLY Ø1.5"(38mm)x5'(1.5m) FOR ARU WITH PVC FEMALE CAMLOCK ON BOTH ENDS
381092	1	DRAIN HOSE ASSEMBLY 0.75"(19mm)x5'(1.5m)CLEAR HOSE WITH 0.75"(19mm) PVC FEMALE CAMLOCK
381351	1	WAND PVC DOUBLE BEND 54"(1.4m) FOR ARU WITH MALE CAMLOCK
381354	1	CREVICE NOZZLE ASSEMBLY FOR ARU, 12" (30.5cm), BLACK POLYPROPYLENE, WITH MALE CAMLOCK ON ONE END
381353	1	CREVICE NOZZLE ASSEMBLY FOR ARU, 36" (91cm), BLACK POLYPROPYLENE, WITH MALE CAMLOCK ON ONE END
381355	1	SQUEEGEE TOOL 14"(35.6cm) PVC WITH EPDM RUBBER BLADES FOR USE WITH ARU

TOOLS AND	ACCES	SSORIES - Optional
Part#	Qty	Description
381352	1	WAND ASSEMBLY 48"(1.2m) -NYLON FOR ARU

WARNINGS:

WARNING!

OPERATORS MUST WEAR PROPER CLOTHING $\hfill \square$ GLOVES, APRON, EYE AND FOOT PROTECTION $\hfill \square$ BEFORE OPERATING THIS UNIT.

Tel: +(44)0115 928 1508

Do not use these units to recover explosive dusts or flammable liquids